

MossBack Reef Kits Assembly

(Reef Kit, Mega Reef Kit)

1. Insert trunks into post base and secure with provided self-tapping screws. **TIP:** Note the correct orientation of the V shape. There are **NO** pre-drilled holes for the self-tapping screws.
2. Insert one limb into the second V from the top of each trunk. (see diagram below).
3. Lay shade top over top of trunks and secure by inserting limbs in top row of V's on top of each trunk (see diagram below).
4. Insert limbs in the remaining V's on each trunk.
5. Place gravel, concrete block(s), or bag of concrete in base to weigh product down.

Do not place in swimming or boating areas. Check your local game laws.

Note the depth and direction of boat lift when placing your habitat.

