

# MossBack Root Wad Kit & Mega Root Wad Kit Assembly

1. Insert ONE LIMB into the BOTTOM V shape slot on each trunk (see diagram).
2. Insert trunks into all post bases and secure with provided self-tapping screws. TIP: Note the correct orientation of the V shape. There are NO pre-drilled holes for the self-tapping screws.
3. Insert one limb into the second V from the top of each trunk (see diagram).
4. Lay shade top over top of trunks and secure by inserting limbs in top row of V's on top of each trunk (see diagram).
5. Insert limbs in the remaining V's on each trunk.
6. Place gravel, concrete block(s), or bag of concrete in base to weigh product down.

Do not place in swimming or boating areas.  
Check your local game laws.  
Note the depth and direction of boat lift when placing your habitat.  
See product assembly online at [MossbackFishHabitat.com](http://MossbackFishHabitat.com).

