

# BLOCK ADAPTER (2 lbs.)

One base plate affixed to an 11 inch connector sleeve, one top plate, two screws



*(for use with Root Wad\*, Safe Haven, Safe Haven XL, Trophy Tree, Trophy Tree XL, Predator Prey Combo Tree, and John Godwin Signature Crappie Tower)*

1. Place concrete block over base unit.

2. Place top plate over base unit pipe to rest on concrete block.

3. Slide trunk down over the base unit pipe. *(\*Note: the Root Wad trunk WILL NOT fit flush with the top plate on block. Insert bottom limb first, hold trunk level, and insert 3 screws to secure)*

4. Secure the trunk to the base unit pipe with three self-tapping screws. The optimal placement for screws is 1 1/3" below bottom limb.

