DOCK PRO KIT (45 lbs.)





- Before assembling, pull cable kit out of trunk so it doesn't interfere with limb placement.
- 2. Insert limbs in "V" shaped slots in each trunk.
- 3. Wrap the **chain** around any part of the dock frame that is structurally sound. Secure with **quick link**. **Do NOT wrap the** *cable* **around the dock structure** it can cause damage to the cable and/or your dock over time. Cable kits will add at least 5 feet of depth to your vertical product. Depending on placement, the attached chain can also add additional depth. If you want to adjust the depth, do so *only by adjusting the chain* **not wrapping the cable**. Depth can also vary if the product is hung from a support that is close to or far from the water.


IMPORTANT NOTE:

Attach product to the dock BEFORE placing it in the water.

4. Place Safe Haven between the two Trophy Trees for maximum fishing area.

For deeper placement we recommend three of our depth extenders (sold separately).

Note the depth and direction of boat lift when placing your habitat.



chain

