

# PREDATOR PREY KIT (50 lbs.)

One Triangle Base and Shade Top, nine Screws, two Trophy Tree trunks, one Safe Haven trunk, thirty-six 46" limbs



1. Insert trunks into post base and secure with provided self-tapping screws.  
**TIP: Note the correct orientation of the V shape.**  
There are **NO** pre-drilled holes for the self-tapping screws.
2. Insert one limb into the second V from the top of each trunk (see diagram).
3. Lay shade top over top of trunks and secure by inserting limbs in top row of V's on top of each trunk (see diagram).
4. Insert limbs in the remaining V's on each trunk.
5. Place gravel, concrete block(s), or bag of concrete in base to weigh product down (not included).

