

REEF KIT (88 lbs.)

One 9-post base and shade top, fifteen screws, four Trophy Tree trunks, one Safe Haven trunk, fifty-four 46" limbs



1. Insert trunks into post bases (as pictured below) and secure with provided self-tapping screws. Safe Haven trunk goes in center post base.
TIP: Note the correct orientation of the V shape.
There are NO pre-drilled holes for the self-tapping screws.
2. Insert one limb into the second V from the top of each trunk. (see diagram below).
3. Lay shade top over top of trunks and secure by inserting limbs in top row of V's on top of each trunk (see diagram below).
4. Insert limbs in the remaining V's on each trunk.
5. Place gravel, concrete block(s), or bag of concrete in base to weigh product down (not included).

