

ROOT WAD KIT (32 lbs.)

One Triangle Base and Shade Top, nine screws,
three 20" Root Wad trunks, twenty-seven 46" limbs



1. Insert ONE LIMB into the BOTTOM V shape slot on each trunk (see diagram).
2. Insert trunks into all post bases and secure with provided self-tapping screws. **TIP:** Note the correct orientation of the V shape.
There are NO pre-drilled holes for the self-tapping screws.
3. Insert one limb into the second V from the top of each trunk (see diagram).
4. Lay shade top over top of trunks and secure by inserting limbs in top row of V's on top of each trunk (see diagram).
5. Insert limbs in the remaining V's on each trunk.
6. Place gravel, concrete block(s), or bag of concrete in base to weigh product down (not included).

