

## SPAWNING BED (14 lbs.)

One Round Base, one 20" Root Wad trunk, nine 46" limbs, three screws



1. Insert trunk into base where slits appear as "V" shapes.  
Attach to base with provided screws.
2. Insert limbs, adjusting two of the top limbs to extend over the bed.  
(See diagram below). Adjust remaining limbs to extend over sides and rear of the bed for side and rear protection of nest.
3. Cover the bed with gravel substrate no more than half full (not included).
4. Place bed in 3'- 8' of water depending on your water clarity.

