

MossBack Fish Magnet Set-Up

1. Remove from box and unfold.
2. Turn underneath limbs to desired direction.
3. Fill mesh bag with chum or live bait. Bag can also be used for weighting objects if needed in current.
4. Use quick-link to attach to cleat on boat, or loop cable around dock, pier, or bridge and clip quick-link to cable.

Do not place in swimming or boating areas. Check your local game laws.
See product assembly online at MossbackFishHabitat.com.

