

MossBack Depth Extender

Use quick-link and chain section to suspend habitat from your dock (figure 1) or secure habitat to a concrete block (figure 2). Do not loop cable. Connect cables with provided quick link.

Do not place in swimming or boating areas. Check your local game laws.

Note the depth and direction of boat lift when placing your habitat.

See product assembly online at MossbackFishHabitat.com.

