

FISH MAGNET *(5 lbs.)*

One Fish Magnet, one mesh bag



1. Remove from box and unfold.
2. Rotate underneath limbs to 90°.
3. Fill mesh bag with chum or live bait. Bag can also be used to hold weighting objects if needed in current.
4. Use quick-link to attach to cleat on boat, or loop cable around dock, pier, or bridge and clip quick-link to cable.

